

How to use

- Place the security strap on the Flexible Arm Mount. It will ensure you won't lose the whole mounting system holding your Deeper device.
- Mount Deeper device to the Flexible Arm Mount. Use a top attachment point.
- Fasten a crab clamp to the Flexible Arm Mount.
- Attach the mounting system to your water craft. For an optimal security fasten the crab clamp to a circular object. Fasten the other end of security strap to your water craft not the mounting system itself.

Make sure to fasten Flexible Arm Mount securely, when properly applied it will never get lost or damaged.

Flexible Arm Mount clamp is easy to remove and relocate. You can clamp your Deeper device to objects ranging in size from 0.2in / 0.5 cm to 2.4in / 6 cm, that makes the Flexible Arm Mount system perfect for diverse marine environments.